

Assembly Instructions :: Ski Adirondack Chair

Green Mountain Ski Furniture

www.greenmtskifurniture.com



Contents:

- 1 chair seat
- 1 chair back
- 2 arms/front legs
- 4, 2-1/2" square drive stainless steel screws
- 8, 2" carriage bolts (stainless)
- 8 flat washers + 8 lock-washers (stainless)
- 8 nuts (stainless)
- 2, 1-5/8" square drive stainless steel Screws

Tools Required:

Square drive #2 bit or screwdriver

7/16" wrench or socket (or adjustable wrench)

Optional:

Power drill-driver AKA: screw-gun (Recommended)

1 or 2 pair non-marking clamps



Step 1: Attach chair back to the chair seat.

Line up the back edge of the lower back support with the pencil line on the top edge of the back leg. Make sure the lower back support is centered on the back legs and firmly seated (clamps are helpful but not necessary).



Attach using the four (4) 2-1/2" stainless steel screws in the pre-drilled holes. It will be very helpful to use a power drill-driver, but this can also be done by hand.

NOTE: *Only screw the heads in until they are flush with the wood surface; cedar is soft wood and it will not take much to do this!*



Step 2: Attach the front legs/arms to front of seat.

(Note: How to tell to Left from Right side: The small arm support bracket goes on the outside of the chair and the cut-out section in the arm goes on the inside.)



Step 2: continued...

Carefully tip the chair over on a side (the back is heavy and you don't want to pull out the screws you just attached...so be careful!)

Push two (2) 2" carriage bolts into the holes on the front leg aligned with the holes in the front of the seat base.

Ideally you will want to line up the square underside of the bolt with the square hole in the wood.

Slide on 1 flat washer, then 1 lock-washer, and thread on a nut. **Apply pressure to the round top of the bolt with your thumb**, and tighten the nut until it just pulls into the wood using a 7/16" wrench. (Again, cedar is soft wood and you don't want to recess the head of the bolt into the wood; it should be flush).

There is one small screw hole (one on each side) near the bolts on the front legs, secure with the small 1-5/8" square-drive screws. Screw heads should be slightly recessed into wood.

Flip the chair over and repeat the process on the other side.

Step 3: Attach arms to upper back support.

Align holes in both parts and push carriage bolts through; again, take care to **align square underside of bolts with any square indents in the wood.**

Slide on 1 flat washer and 1 lock-washer for each bolt, and thread on the nut. While **applying thumb pressure** to the round top of the carriage bolt, tighten the nut until the bolt just pulls into the wood and is flush on the top of the arm.

Step 4: Relax and enjoy your recycled ski furniture!



Please contact us with any questions or for further assistance with assembly. Check us out on-line for other products and accessories such as stools or chair covers.

email: info@greenmtskifurniture.com

phone: 802-324-1717

web: www.greenmtskifurniture.com

